

the **box**

Achat 112M full-range speaker



user manual

Musikhaus Thomann e.K. Treppendorf 30 96138 Burgebrach Germany Telephone: +49 (0) 9546 9223-0 email: info@thomann.de Internet: www.thomann.de

26.01.2012

Table of contents

1	General notes	4
2	Safety instructions	
3	Features	
4 Installation		10
	4.1 Tips on handling speakers	12
	4.2 Hanging the speaker box	13
	4.3 Connections	14
5	Technical specifications	15
6	Protecting the environment	16



1 General notes

	This user manual contains important information on the safe operation of the device. Read and follow all safety notes and all instructions. Save this manual for future reference. Make sure that it is available to all persons using this device. If you sell the device to another user, be sure that they also receive this manual.
	Our products are subject to a process of continuous development. We therefore reserve the right to make changes without notice.
Symbols and signal words	This section gives an overview of the symbols and signal words used in this user manual.



Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
WARNING!	This combination of symbol and signal word indicates a possible dangerous situation that can result in death or serious injury if it is not avoided.
CAUTION!	This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.



Warning signs	Type of danger
	Warning – suspended load.
	Warning – danger zone.



2 Safety instructions

Intended use

This device is intended to be used in a sound reinforcement system. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

Safety



DANGER!

Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.





CAUTION!

Possible hearing damage

The device can produce volume levels that may cause temporary or permanent hearing impairment. Over an extended period of time, even levels that seem to be uncritical can cause hearing damage.

Decrease the volume level immediately if you experience ringing in your ears or hearing impairment. If this is not possible, keep a greater distance or use sufficient ear protectors.



NOTICE!

Operating conditions

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.



3 Features

Special features of the device:

- Connections: 4 lockable NL4 sockets (SpeakON)
- For use with 'Achat Amprack', various products are available. Appropriate subwoofers, for example, are: 'the box pro Achat 115Sub' or 'the box pro TP118/800'.
- Flying tracks on top side and an eyelet on the back to tilt the box. Required attachment for vertical mounting 'the box Achat Flying Track Attachment' (2 pcs. per box).
- Pole mount flange, 36 mm at the bottom
- Rotatable horn
- Black textured coating



4 Installation

Unpack and check carefully there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the device against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.

Establish all connections as long as the unit is switched off. Use the shortest possible highquality cables for all connections.



WARNING!

Risk of injury caused by falling objects

Make sure that the installation complies with the standards and rules that apply in your country. Always secure the device with a secondary safety attachment, such as a safety cable or a safety chain.



NOTICE!

Possible property damage by magnetic fields

Loudspeakers produce a static magnetic field. Therefore, maintain an appropriate distance to devices that can be adversely affected or damaged by an external magnetic field.



NOTICE!

Use of stands

When mounting the device onto a stand, ensure that the stand is in a safe and stable position and that the weight of the device does not exceed the maximum permissible load capacity of the stand.



4.1 Tips on handling speakers

We recommend you to set up the speakers in a way, that the sound signals can reach the audience unobstructedly. It will often be helpful to mount the speakers on tripods. Thus, the sound will be evenly spread with maximum range throughout the audience area.

Always use high grade cable to connect your equipment. Otherwise you won't reach maximum sound quality.

For optimum results both impedance and power handling of the speakers must match the requirements of the amplifier. Always follow the technical specifications of the speakers! The overall impedance of the connected loudspeakers must not deceed the minimum output impedance of the amp. The amps RMS output power should be 50 % above the power handling capacity of the connected speakers.

If you notice distortion during operation, either the amp or the speaker is overloaded. This may permanently damage the amp or the speaker. Always reduce the volume when you hear distortion.

thomann MUSIC IS OUR PASSION


4.2 Hanging the speaker box

To hang the speaker box on special mounting devices (aka 'flying') both sides of the box offer built-in Aeroquip or fly tracks. In these tracks safety eyelets (double studs) can be screwed or latched. Check the secure connection of the safety eyelets with the box carefully, before you use it in 'flying mode'.

Using an additional loop on the back of the box, it is possible to tilt the box. This additional loop must not solely be in charge to secure the entire suspended weight.



4.3 Connections




1, 2 2 NL4 connections wired in parallel on the rear panel (SpeakON)

1 additional NL4 connection is located on the top side and 1 on the bottom side of the cabinet. Find more information about the wiring of the NL4 connections on the rear panel of the cabinet.

NL4 mounting connectors for speaker connections

The drawing alongside shows the pin assignment of the lockable NL4 mounting connectors.



5 Technical specifications

System	2-way full-range speaker box with built-in crossover
Speakers	1 × 12" woofer, 1.4" mid-high driver (with 3" voice coil)
Power handling	350 W (RMS), 1400 W (peak)
Impedance	8Ω
Maximum SPL	131 dB
Frequency response	60 Hz 18 kHz (–3 dB)
Dispersion (V × H)	60° × 40° (tweeter)
Dimensions ($W \times H \times D$)	360 mm × 610 mm × 360 mm
Weight	19.8 kg



6 Protecting the environment

Disposal of the packaging material



Disposal of your old device



This device is subject to the European directive 2002/96/EC.

chosen that can be supplied to normal recycling.

Do not dispose the device with your normal household waste.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Dispose this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.

For the transport and protective packaging, environmentally friendly materials have been

Do not just dispose these materials with your normal household waste, but make sure that

they are fed to a recovery. Please follow the notes and markings on the packaging.





Musikhaus Thomann e.K. · Treppendorf 30 · 96138 Burgebrach · Germany · www.thomann.de