


# TA18 active subwoofer





user manual

Musikhaus Thomann Thomann GmbH Hans-Thomann-Straße 1 96138 Burgebrach Germany Telephone: +49 (0) 9546 9223-0 E-mail: info@thomann.de Internet: www.thomann.de

24.10.2019, ID: 191413 (V3)

# **Table of contents**

1	General information	4
	1.1 Further information	
	1.2 Notational conventions	
	1.3 Symbols and signal words	б
2	Safety instructions	9
3	Features	4
4	Installation	5
5	Connections and controls 1	7
6	Technical specifications	9
7	Plug and connection assignment 2	1
8	Cleaning and care 24	
9	Protecting the environment	5



# 1 General information

This user manual contains important information on the safe operation of the device. Read and follow all safety notes and all instructions. Save this manual for future reference. Make sure that it is available to all persons using this device. If you sell the device to another user, be sure that they also receive this manual.

Our products and user manuals are subject to a process of continuous development. We therefore reserve the right to make changes without notice. Please refer to the latest version of the user manual which is ready for download under <u>www.thomann.de</u>.



## 1.1 Further information

On our website (<u>www.thomann.de</u>) you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.
Keyword search	Use the search function in the electronic version to find the topics of interest for you quickly.
Online guides	Our online guides provide detailed information on technical basics and terms.
Personal consultation	For personal consultation please contact our technical hotline.
Service	If you have any problems with the device the customer service will gladly assist you.

th.mann

## **1.2 Notational conventions**

This manual uses the following notational conventions:

Letterings

The letterings for connectors and controls are marked by square brackets and italics. **Examples:** [VOLUME] control, [Mono] button.

## **1.3** Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.



Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
WARNING!	This combination of symbol and signal word indicates a pos- sible dangerous situation that can result in death or serious injury if it is not avoided.
CAUTION!	This combination of symbol and signal word indicates a pos- sible dangerous situation that can result in minor injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a pos- sible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
	Warning – high-voltage.



thomann MUSIC IS OUR PASSION

Warning signs	Type of danger
	Warning – suspended load.
	Warning – danger zone.



# 2 Safety instructions

#### Intended use

This device is designed for sound reinforcement. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.



#### DANGER!

#### **Danger for children**

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.





## DANGER!

#### Electric shock caused by high voltages inside

Within the device there are areas where high voltages may be present. Never remove any covers.

There are no user-serviceable parts inside.

Do not use the device if covers, protectors or optical components are missing or damaged.



#### DANGER!

#### Electric shock caused by short-circuit

Always use proper ready-made insulated mains cabling (power cord) with a protective contact plug. Do not modify the mains cable or the plug. Failure to do so could result in electric shock/death or fire. If in doubt, seek advice from a registered electrician.





## CAUTION!

## Possible hearing damage

The device can produce volume levels that may cause temporary or permanent hearing impairment. Over an extended period of time, even levels that seem to be uncritical can cause hearing damage.

Decrease the volume level immediately if you experience ringing in your ears or hearing impairment. If this is not possible, keep a greater distance or use sufficient ear protectors.



#### NOTICE!

#### **Risk of fire**

Do not block areas of ventilation. Do not install the device near any direct heat source. Keep the device away from naked flames.

MUSIC IS OUR PASSION

#### NOTICE!

#### **Operating conditions**

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.

Only operate the device within the ambient conditions specified in the chapter 'Technical specifications' of this user manual. Avoid heavy temperature fluctuations and do not switch the device on immediately after it was exposed to temperature fluctuations (for example after transport at low outside temperatures).

Dust and dirt inside can damage the unit. When operated in harmful ambient conditions (dust, smoke, nicotine, fog, etc.), the unit should be maintained by qualified service personnel at regular intervals to prevent overheating and other malfunction.

th•mann

#### NOTICE!

#### Power supply

Before connecting the device, ensure that the input voltage (AC outlet) matches the voltage rating of the device and that the AC outlet is protected by a residual current circuit breaker. Failure to do so could result in damage to the device and possibly injure the user.

Unplug the device before electrical storms occur and when it is unused for long periods of time to reduce the risk of electric shock or fire.



## NOTICE!

#### Possible damage due to installation of a wrong fuse

The use of different types of fuses can cause serious damage to the unit. Fire hazard!

Only fuses of the same type may be used.



## 3 Features

Special features of the device:

- Speakers: 1 × 18" woofer
- M20 flange for speaker pole
- Optional infrared remote control (item no. 222250)



# 4 Installation

Unpack and check carefully there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the product against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.

Create all connections while the device is off. Use the shortest possible high-quality cables for all connections. Take care when running the cables to prevent tripping hazards.



#### WARNING!

#### Risk of injury caused by falling objects

Make sure that the installation complies with the standards and rules that apply in your country. Always secure the device with a secondary safety attachment, such as a safety cable or a safety chain.

MUSIC IS OUR PASSION



# CAUTION!

Risk of injury due to heavy weight

Due to the heavy weight of the device, at least two persons are required for transport and installation.




## NOTICE!

#### Possible property damage by magnetic fields

Loudspeakers produce a static magnetic field. Therefore, maintain an appropriate distance to devices that can be adversely affected or damaged by an external magnetic field.

th•mann MUSIC IS OUR PASSION

#### **Connections and controls** 5



Volume control for the
decrease the volume b

input. Turn this control clockwise to increase the volume. y rotating counter-clockwise. First please adjust the volume to minimum before switching the unit on or making connections. Then adjust the appropriate volume.

#### 2 [ACTIVE]

This LED lights up when the unit is switched on.

3 [INPUT]

Connect the stereo line input signals for channels L & R to these balanced mounting plugs.

4 [115 V/230 V]

Power supply switch Make sure this selector is set correctly for the actual supply voltage at the operating location. Use this switch only when the device is switched off.

th mann

5	[ON/OFF]
	Use this mains switch to turn the device on or off.
6	[INV]
	Phase inversion switch.
7	[HIGH CUT]
	Turn this control to adjust the frequency of the high cut filter between 80 Hz and 250 Hz.
8	[LIMIT]
	This LED lights up when the limiter circuit becomes active.
9	[OUTPUT]
	L/R line outputs for the connection of active mid/high speakers.
10	Fuse holder
11	IEC chassis plug for the power supply
	Make sure that the mains control (4) is in the right position, <b>BEFORE</b> connection power supply.

thomann MUSIC IS OUR PASSION

# **6** Technical specifications

Speaker	1 × 18" woofer	
Input connections	Power supply	IEC chassis plug C14
Input impedance	balanced: 20 k $\Omega$ , unbalanced: 10 k $\Omega$	
Output connections	Signal output	2 × XLR chassis plug
Output power	max. 1000 W	
Frequency range	35 Hz 250 Hz, –3 dB	
Distortion	< 2 %	
Sound pressure level (SPL), max.	131 dB (free field)	
Power consumption	500 W	
Supply voltage	115/230 V ~ 50/60 Hz	

th.mann

Fuse	Supply voltage 230 V: 5 mm $ imes$ 20 mm, 5 A, 250 V, slow-blow	
	Supply voltage 115 V: 5 mm $\times$ 20 mm, 8 A, 2	50 V, slow-blow
Dimensions (W $\times$ H $\times$ D)	530 mm $\times$ 580 mm $\times$ 693 mm	
Weight	45 kg	
Ambient conditions	Temperature range	0 °C40 °C
	Relative humidity	50 %, non-condensing

## **Further information**

Design	Bandpass filter
Stand mounting	Yes
Truss-capable	No
Casters	No




# 7 Plug and connection assignment

Introduction	This chapter will help you select the right cables and plugs to connect your valuable equip- ment in such a way that a perfect sound experience is ensured.
	Please note these advices, because especially in 'Sound & Light' caution is indicated: Even if a plug fits into the socket, an incorrect connection may result in a destroyed power amp, a short circuit or 'just' in poor transmission quality!
Balanced and unbalanced trans- mission	Unbalanced transmission is mainly used in semi-professional environment and in hifi use. Instrument cables with two conductors (one core plus shielding) are typical representatives of the unbalanced transmission. One conductor is ground and shielding while the signal is trans- mitted through the core.
	Unbalanced transmission is susceptible to electromagnetic interference, especially at low levels, such as microphone signals and when using long cables.
	In a professional environment, therefore, the balanced transmission is preferred, because this enables an undisturbed transmission of signals over long distances. In addition to the conduc- tors 'Ground' and 'Signal', in a balanced transmission a second core is added. This also transfers the signal, but phase-shifted by 180°.

th.mann

Since the interference affects both cores equally, by subtracting the phase-shifted signals, the interfering signal is completely neutralized. The result is a pure signal without any noise interference.

#### XLR plug (balanced)




3

	Ground, shielding
	Signal (in phase, +)
	Signal (out of phase, –)
,	Shielding on plug housing (option)



## XLR plug (unbalanced)



2 3

Ground, shielding
Signal
Bridged to pin 1



# 8 Cleaning and care

#### Housing

Use only pH-neutral, solvent-free and non-abrasive cleaning agents. Clean the unit with a slightly damp lint-free cloth.



# 9 Protecting the environment

Disposal of the packaging material



#### Disposal of your old device



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose with your normal household waste.

Dispose of this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.



Musikhaus Thomann • Hans-Thomann-Straße 1 • 96138 Burgebrach • Germany • www.thomann.de