

## Features

- ✓ Controls up to 4 pedals
- ✓ 2 x 8 memory banks
- ✓ External power supply
- ✓ True bypass

### Operating elements:

- BANK +/-: Bank switch +/-
- A / B: For selecting the loop groups
- EDIT: Enables the edit mode
- STORE: Saves the programmed matrix
- BANK: Indicates the active memory bank

**Connections:** Instrument input  
4 x in and output to the pedals  
Output for amp connection  
Voltage supply


**Supply:** External power adapter (9 V $\equiv$ , 300 mA), optionally available

**Dimensions:** 283 x 82 x 55 mm (L x W x H)

**Weight:** 0.88 kg

## Description

EN




The programmable Harley Benton 4 x effects looper is the intelligent control centre for up to 4 connectable pedals or rack effects. It features 2 x 8 memory banks, true bypass, a robust housing and reliable foot switches.

The switches A and B turn the selected effect groups on or off. Through the BANK + / - buttons, the desired memory bank can be selected.

The EDIT mode lets you programme and store the desired effect-loop groups.

This unit is operated with an external 9V power adapter (not included).



## Safety instructions



- Ensure that plastic bags, packaging, etc. are properly disposed of and are not in the reach of babies and young children. Choking hazard!
- Do not operate or store the unit in locations, where it is exposed to heat, precipitation, high humidity, pollution, or strong vibrations. Indoor use only!
- Never try to dismantle or repair the unit by yourself in case it doesn't work.
- Never operate the device with a supply voltage other than that stated here. Otherwise the unit will be damaged.
- Never use solvents like alcohol etc. for cleaning the unit.

## Protecting the environment

- Do not just dispose of packaging materials with your normal household waste, but make sure that they are fed to a recovery.
- At the end of its operating lifetime, do not dispose of the device with your normal household waste. This device is subject to the European directive 2002/96/EC. Dispose of this device through an approved waste disposal firm or through your local waste facility.
- Dispose of the batteries according to national or local regulations regarding hazardous waste.

A detailed operating manual can be downloaded from [www.thomann.de](http://www.thomann.de)



Musikhaus Thomann e. K.  
Treppendorf 30 • 96138 Burgebrach  
Germany • [www.thomann.de](http://www.thomann.de)

*Harley Benton*